

# WOOD CLEANING GUIDE

PROBLEMS	Stage 1	Stage 2	Stage 3
Normal dirt Beverage stain Food Stain	Wood Cleaner	Wood Polish for waxed wood, lacquered wood, varnished wood.  Wood Oil for oiled wood	
Grease stain Oil stain	Wood Degreaser for un-varnished wood, lacquered wood.  Half Surface Degreaser for varnished wood, lacquered wood.		
Formation mould on garden and boat furniture.	Teak Cleaner	Teak Brightener	Teak Oil
Greyed colour teak caused by atmospheric contamination.	Teak Cleaner	Teak Brightener	Teak Oil
Stains of Teak Oil or Teak Colour Oil on steel, fibre-glass, wood, glass.	Stain Cleaner		

# WOOD REPAIR GUIDE

PROBLEMS	Stage 1	Stage 2	Stage 3
Slight cracking and fissure.	Wood Cleaner	<p>Wood Polish for waxed wood, lacquered wood, varnished wood.</p> <p>Wood Oil for oiled wood.</p>	
Superficial scratch with damaged surface	Wood Cleaner	<p>Wax &amp; Wood Touch-Up</p> <p>Touch-Up Marker</p>	
Scratch and scrape with marked damage on the surface (house furniture)	Wood Cleaner	<p>Easy Wax Filler</p> <p>(use Touch-Up Marker if you do not get the desired shade).</p>	Touch Up Spray Lacquer
Scratch and scrape with marked damage on the surface (outdoor furniture)	Wood Cleaner	<p>Profi Wax Filler</p> <p>(use Touch-Up Marker if you do not get the desired shade).</p>	Touch Up Spray Lacquer

# PRODUCT SELECTION GUIDE



FURNITURE	Wood Care Kit	Teak Care Kit	Hard Surface Cleaner	Stain Cleaner	Hard Surface Degreaser	Wood Degreaser	Clean Star
<b>Home furniture</b> Drawing room furniture, tables, seats, chairs, rocking chairs, chaise-longue, sideboards, bedframes, doors, door and window frames, fastenings, picture frames, handrails, stairs, chest of drawers, bedside table and cabinets, wardrobes, writing desks, cabinets, shelves, coat hangers, bookcases, mirrors, linenpress.	✓		✓		✓	✓	✓
<b>Bathroom furniture</b> Bathroom floor tiles, wood flooring, bath side panels, cabinets, shelves, linoleum flooring.	✓	✓	✓			✓	✓
<b>Kitchen furniture</b> Tables, seats, work surfaces, cupboards, stools, larder, sideboard, cooker hoods, cooker hobs, ovens.	✓		✓		✓	✓	✓
<b>Outdoor and garden furniture</b> Chairs, deckchairs, tables, sunloungers, armchairs, trolleys, benches, swings, canopies, pergolas, wind breakers, panels, flower boxes, fencing, gates, roofs, flooring, stairs, balconies, footbridges, dog kennels, Wendy houses.		✓				✓	✓
<b>Boat furniture</b> Decks, stairs	✓	✓	✓	✓	✓	✓	✓
<b>Other</b> Musical instruments, packaging, staves, sports equipment, sauna.	✓		✓				



**FURNITURE**

Home furniture  
Drawing room furniture,  
tables, seats, chairs,  
rocking chairs,  
chaise-longue,  
sideboards, bedframes,  
doors, door and  
window frames,  
fastenings, picture  
frames, handrails,  
stairs, chest of drawers,  
bedside table and  
cabinets, wardrobes,  
writing desks, cabinets,  
shelves, coat hangers,  
bookcases, mirrors,  
linenpress.

Wood Furniture Oil  
Beeswax Balm Paste  
Liquid Beeswax  
Wood Touch-Up Kit  
Wood Protector  
Easy Wax Filler  
Profi Wax Filler  
Touch-Up Marker  
Fine Touch-Up Pen  
Touch-Spray Laquer

✓ ✓ ✓ ✓ ✓\* ✓ ✓ ✓ ✓ ✓ ✓

Bathroom furniture  
Bathroom floor tiles,  
wood flooring, bath  
side panels, cabinets,  
shelves, linoleum  
flooring.

✓ ✓\* ✓ ✓ ✓ ✓ ✓

Kitchen furniture  
Tables, seats, work  
surfaces, cupboards,  
stools, larder, sideboard,  
cooker hoods, cooker  
hobs, ovens.

✓ ✓ ✓ ✓ ✓\* ✓ ✓ ✓ ✓

Outdoor and garden  
furniture  
Chairs, deckchairs,  
tables, sunloungers,  
armchairs, trolleys,  
benches, swings,  
canopies, pergolas,  
wind breakers, panels,  
flower boxes, fencing,  
gates, roofs, flooring,  
stairs, balconies,  
footbridges, dog  
kennels, Wendy  
houses.

✓ ✓\* ✓ ✓ ✓ ✓

Boat furniture  
Decks, stairs

✓ ✓\* ✓ ✓ ✓ ✓

Other  
Musical instruments,  
packaging, staves,  
sports equipment,  
sauna.

✓ ✓\* ✓ ✓ ✓ ✓

\* only for unfinished wood surfaces.


# COLOUR CARDS



Beeswax Balm Paste



Liquid Beeswax



Easy Wax Filler



Profi Wax Filler



Fine Touch-up Pen



Touch-up Marker



Colour Restoration Pen



Wood Touch-up Kit

Beeswax Balm Paste	Liquid Beeswax	Easy Wax Filler	Profi Wax Filler	Fine Touch-up Pen	Touch-up Marker	Colour Restoration Pen	Wood Touch-up Kit	Code	Color
		✓	✓	✓	✓	✓		cod. 16 • CHERRY	
		✓	✓	✓	✓	✓	✓	cod. 05 • PINE	
				✓	✓	✓	✓	cod. 41 • NATURAL BEECH	
		✓	✓	✓	✓	✓	✓	cod. 10 • LARCH	
		✓	✓	✓	✓	✓	✓	cod. 30 • CHERRY	
							✓	cod. 66 • DARK-CHERRY WOOD	
		✓	✓					cod. 62 • MAHOGANY	
				✓	✓	✓	✓	cod. 33 • DARK-MAHOGANY	
	✓	✓	✓					cod. 51 • LIGHT OAK	
✓		✓	✓					cod. 48 • MEDIUM OAK	
	✓	✓	✓	✓	✓	✓	✓	cod. 52 • DARK OAK	
		✓	✓	✓	✓	✓	✓	cod. 17 • TEAK	
		✓	✓	✓	✓	✓	✓	cod. 59 • MEDIUM WALNUT P11	
				✓	✓	✓	✓	cod. 60 • BLACK	
✓	✓							cod. 120 • YELLOW	